

PRODUCTIVE ANALYTICS

A Cloud Based System For Remote Monitoring All Your OB7 Robots

Productive Analytics provides live, real time, status monitoring of your OB7 robots. The current operating status for all your robots, as well as their entire production history is displayed. The currently running job, past jobs run, running hours, production results, production errors, job run times and robot idle times are all presented. All data transmitted from the robot is encrypted. Your robot's data is stored on secure AWS (Amazon Web Service) servers.

Home Reports

Machine Shop

cnc OFFLINE

Current Job: **Job 17**

Cycles Run: **0** today **N/A** total

Run Time: **N/A** Cycle Time: **N/A**

Production Floor

debur OFFLINE

Current Job: **Job 31**

Cycles Run: **0** today **N/A** total

Run Time: **N/A** Cycle Time: **N/A**

Current Status of All Your Robots

Home Reports

Robot List

Robot: cnc

Serial Number: 18093478
 Location: [Machine Shop](#)
 Last Check-in: 06/02/2020 08:32:28 PDT

[Overview](#)
[Performance](#)
[Features](#)

cnc OFFLINE

Current Job: **Job 17**

Cycles Run: **0** today **N/A** total

Run Time: **N/A** Cycle Time: **N/A**

[Job List](#)
[Job Errors](#)

Job Name	Taught By	Last Run Start	Last Run Stop	Cycles	Cycle Time	Total Run Time
▶ Final MAC290 on VF3 Stoc...		05/22/20	05/23/20	121	17 mins 15 secs	69 hrs 57 mins
▶ Copy of movie MAC290 o...		05/20/20	05/20/20	0		
▶ move it		04/29/20	04/30/20	35705	38 secs	145 hrs 37 mins
▶ mac134		02/04/20	02/06/20	13057	12.2 secs	44 hrs 18 mins
▶ Pick up and Drop		01/16/19	01/16/19	85	6.6 secs	9 mins 23 secs
▶ Job created: Fri, 31 Aug 4:...		08/31/18	09/04/18	8280	42 secs	95 hrs 37 mins

Load More

Production History of Any Robot



Productive Analytics Features

- Productive Analytics provides automated scheduled reports via email. Reports can be delivered as both PDFs and CSV files for import into your company's production data systems.
- No network ports on OB7 are kept open assuring safety from hacking or malware.
- Productive Analytics provides you with the information you need to optimize your production, identify production errors and bottlenecks, minimize downtime, and monitor actual production output from your OB7 robots.
- Production data from OB7 can be transmitted via either wired network, wirelessly through wifi, or through your own private cellular connection.

